

## How to Order

<b>DMK</b>		<b>6</b>	—	<b>04</b>	—	
		Number of connecting tubes		Accessory (Option)		
		6	6	Nil		
		12	12	C1		
				C2		
				None		
				Cover single side 1 pc.		
				Cover both sides 2 pcs.		
		Type		Tubing O.D.		
		Nil	Multi-connector	23		
		P	Plug side only	04		
		S	Socket side only	ø3.2		
				ø4		

## ⚠ Precautions

Be sure to read this before handling the products.


Refer to back page 50 for Safety Instructions and pages 13 to 17 for Fittings and Tubing Precautions.

## How to Use

### ⚠ Caution


#### Disassembly

- Loosen clamp ring A and disassemble the connector into the plug case and socket case.




#### Connection

- Turn the cases while pressing them against each other until the plug case slides into the socket case at a proper position.
- Align at mark B of the plug and socket cases and turn them against each other to connect the two cases.
- Screw in the clamp ring to complete the connection.



#### Installation of cover

- The cover can be installed on both the plug case or socket case.
- Stretch the cover to install on the cover installation latch.



### ⚠ Caution

Please do not attach metal rods or metal pipes. Metal rods or pipes cannot be secured and the fittings will shoot out. Also, if tubes are attached after metal rods or pipes have been attached, the tubes will not hold and may come loose.

## Installation and Removal of One-touch Mini Fittings


### ⚠ Caution

#### Installation of tubing

- Cut the tube perpendicularly, using caution not to damage its surface. (Use tube cutter TK-1, 2 or 3. Do not cut the tube with cutting pliers, nippers, scissors, etc.)
- Grasp the tube, then slowly push it until it comes to a stop.
- Then, pull it back gently to make sure that it does not come out.

#### Removal of tubing

- While pushing down on the rim of the release button, pull out the tube in the direction of the arrow (see illustration.) The release button can also be pushed down with a flat-head screwdriver. However, be careful not to break or damage the release button.
- To reuse the released tube, cut off the damaged portion of the tube.



KQ2  
KQB2  
KS  
KX  
KM  
KF  
M  
H/DL  
L/LL  
KC  
KK  
KK130  
DM  
KDM  
KB  
KR  
KA  
KQG2  
KG  
KFG2  
MS  
KKA  
KP  
LQ  
MQR  
T  
IDK